

Installation Instruction


Item No: 8113-TL

1. Carefully unpack and take out the parts as picture shown.
2. Squeeze harp (C) together and insert into saddle (B) tightly.
3. Attach the shade (D) onto harp (C), then screw the finial (E).

*** HARP MAY HAVE TO BE REMOVED TO INSTALL BULB**

Important Safety Instruction

This portable lamp has a polarized plug (One blade is wider than the other) as a safety feature to reduce the risk of the electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.



Note: 120V/150W

WARNING ! – To reduce the risk of fire ,electric shock, or personal injury:

- Turn off / unplug lamp and allow to cool before replacing bulb.
- Do not touch bulb when fixture is turned on
- Do not look directly at lighted bulb
- keep materials that burn easily away from lighted bulb

CLEANING:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish

★ Keep this instruction for future reference