


Caution

- This product is fragile and should be assembled with care.
- Please follow the below steps and requirements specified in the instruction to ensure safety and reliability during the installation.

Schematic diagram




Component list

No.	Name	Quantity
1	Adapter	1 pc
2,3	Power Wire (longer +shorter)	2 pc
4	Holder - Lower	1 pc
5	Holder- Middle	1 pc
6	Holder- Upper	1 pc
7	Lamp	1set
8	Topper	1 pc
9	Screws (bigger +smaller)	4+8 pcs
1,2,3,4	All wire connectors.	


Assembly Instructions

1) Assemble the holder




Assemble the 3 parts of the holder into a hole with 8 screws.
Note: Be sure to have the corresponding anchor points lined up correctly before fixing.

2) Connect wires



- (A) Thread the shorter power wire and its connector (4) through the holder and then fix the holder onto the bottom of lamp with 4 bigger screws.
- (B) Fix two connectors (3) and (4) to combine two power wires of 2 and 3.

3) Power on and enjoy



- (A) Fix two connectors (1) and (2), and then connect the adaptor with the main power source.
- (B) Set the switch on the bottom of the lamp to the left. The lights should be lit, snowflakes should be falling and music should be playing. If it fails to perform such functions, check if the connectors are well connected until it can perform the functions. You can also turn the switch to the right side to turn off the music.